## Abdichtung im Verbund mit dem OTTOFLEX® System



C2-Kleber		OTTOFLEX® Abdichtbahn
Ardex N 23 Microtec Naturstein	<b>⊗</b>	<b>⊗</b>
Ardex X 7 G plus	<b>©</b>	<b>©</b>
Botament Multistone	<b>©</b>	<b>Ø</b>
Botament M 21 Classic	<b>Ø</b>	<b>Ø</b>
Codex Power CX 1	<b>Ø</b>	<b>⊗</b>
Codex Stone SX 80	<b>Ø</b>	<b>⊗</b>
Mapei Keraquick S1	<b>Ø</b>	<u> </u>
Mapei Ultralite S1	<b>Ø</b>	<u> </u>
PCI FT Extra	<b>⊗</b>	<b>⊗</b>
PCI Flexmörtel	<b>©</b>	Х

C2-Kleber	0 1 1 01 ==21	OTTOFLEX® Abdichtbahn
PCI Flexmörtel S1	<b>⊗</b>	<b>⊗</b>
Sakret FFKs	<b>©</b>	<b>©</b>
Sakret Flexfliesenkleber FFK	<b>⊗</b>	<b>©</b>
Schomburg Monoflex	<b>⊗</b>	<b>Ø</b>
Schomburg Soloflex	<b>©</b>	<b>Ø</b>
Schönox Q6	<b>⊗</b>	<b>⊗</b>
Sopro FKM XL	<b>⊗</b>	<b>⊗</b>
Sopro Fliesenkleber No. 1	<b>⊗</b>	<b>⊗</b>
weber.xerm 852	<b>Ø</b>	<b>⊗</b>
weber.xerm 861	<b>©</b>	<b>©</b>

